

V-TAC

Meaningful Innovation.

INSTRUCTION MANUAL TOUCH SENSOR

TECHNICAL DATA

MODEL	VT-8165
SKU	24358
INPUT VOLTAGE	AC: 220-240V, 50/60 Hz
RATED CURRENT	6A
RATED LOAD	Max. 1200W ⚡ 600W ⚡ +LED
WOOD/GLASS THICKNESS	≤ 40mm
POWER CONSUMPTION	<05W
WORKING TEMPERATURE	-20°C to +50°C
IP RATING	IP20
DIMENSION	



COMPATIBLE WITH
V-TAC LED
RANGE (UPTO 600W)


05 YEAR
WARRANTY*

INTRODUCTION & WARRANTY


Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 5 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product.



This marking indicates that this product should not be disposed of with other household wastes.



Caution, risk of electric shock.



MULTI-LANGUAGE MANUAL QR CODE

Please scan the QR code to access the manual in multiple languages.



FR

Cet appareil, ses accessoires et cordons se recyclent

À DÉPOSER EN MAGASIN



À DÉPOSER EN DÉCHÈTERIE



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

WARNING

1. Please make sure to turn off the power before starting the installation.
2. Installation must be performed by a qualified electrician.
3. For indoor use only.

INSTALLATION INSTRUCTIONS

1. Switch off the power supply.
2. Install the product's sensing component on the wooden or glass door (thickness ≤ 40 mm) using double-coated adhesive tape. Install the product's power unit on the wall using the two supplied expansion screws, as shown in Figure 1.
3. Connect the power supply and load to the sensor according to the wiring diagram.
4. Switch on the power supply and test the operation as shown in Figure 2.




Figure 1





Figure 2

WIRING DIAGRAM



TEST

1. Switch on the power supply.
2. When your hand touches the back side of the object where the sensor is installed, the sensor detects the action and turns the light on immediately. The light will switch off when the IR sensor detects another touch by hand.



V-TAC WEST EUROPE LTD. IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT, PLEASE REACH OUT TO US AT: SUPPORT@V-TAC.EU FOR MORE PRODUCTS RANGE, INQUIRY PLEASE CONTACT OUR DISTRIBUTOR OR NEAREST DEALERS. V-TAC WEST EUROPE LTD. GROUND FLOOR, 71 LOWER BAGGOT STREET, DUBLIN O2, IRELAND DO2 P593

V-TAC UK LTD. IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT PLEASE REACH OUT TO US AT SUPPORT@VTACEXPORTS.COM V-TAC, 5A TUNGSTEN PARK, DOWNS ROAD, WITNEY, OXFORDSHIRE, OX29 OAX